



O.G. HEAVY DUTY

split wall-mounted air conditioner

User's Manual

**Read the manual carefully before operation and keep it for reference.
This manual is only for reference, please comply with actual appliance
you selected. manufacturer hold the authority to redesign or modify its
products without notice.**

SAFETY PRECAUTIONS



WARNING: Following these basic precautions will reduce the risk of fire, electrical shock, injury or death when using your air conditioner.

1. Air conditioner must be connected to proper electrical outlet or breaker with the correct electrical supply. And only the specified power can be used.
2. Proper grounding must be ensured to reduce the risk of shock and fire
DO NOT CUT OR REMOVE THE GROUNDING PRONG. If you do not have a three-prong electric receptacle outlet or breaker in the wall, have a certified electrician install the proper receptacle or breaker. The wall receptacle or breaker **MUST** be properly grounded.
3. **DO NOT** use if power cord is frayed or otherwise damaged. Also avoid using it if there are cracks or abrasion damage along the length, plug or connector.
4. **DO NOT** USE AN ADAPTER OR AN EXTENSION CORD.
5. **DO NOT** block airflow inside or outside the air conditioner with blinds, drapes, protective covers, shrubs or blusher.
6. Be careful of sharp edges on the front and rear fins of the unit that could cut and cause serious injury.
7. Be careful when lifting the air conditioner to install or remove the unit. Always use two or more people for this.
8. Always cut off the power of air conditioner before servicing it or moving it.
9. In some type of units, there is no appropriate plug corresponding to its power cord because of power, Under this condition, an appropriate power breaker should be linked to its power cord, therefore, the instruction part associated with plug using is not available for these types.
10. An all-pole disconnection switch having a contact separation of at least 3mm in all poles should be connected in fixed wiring.
11. The appliance shall be installed in accordance with national wiring regulations.
12. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

CONTENTS

1. SAFETY INSTRUCTIONS

Symbol Description.....	2
Installation Instruction.....	2
Operating Instruction.....	3
Safety Instruction... ..	6

2. PRODUCT INTRODUCTION

Protect Functions.....	7
------------------------	---

3. DESCRIPTION OF COMPONENTS

View of Unit.....	8
Display screen.....	9
Indicator light.....	10
Remote Controller.....	11
Remote Controller Display.....	12

4. OPERATING METHOD

Smart Operation.....	13
Emergency Run.....	13
Cool, Dry and Heat Operation.....	14
Off Timer.....	15
How to Adjust Air Flow.....	15
Sleep Operation.....	15

5. SERVICE AND MAINTENANCE

Clean the Front Panel and Remote Controller.....	16
Clean Air Filter.....	16
No Use for Long Time.....	17
Recommendations for Energy Saving.....	18

6. TROUBLE SHOOTING

Air Conditioner is in Error.....	19
Remote Controller is in Error.....	19

7. NORMAL PHENOMENONS.....20

8. INSTALLATION MANUAL21

SAFETY INSTRUCTIONS

〔Symbol Description〕



Warning:

A symbol indicating operation which may cause personnel casualties or serious damages.



Caution:

A symbol indicating operation which may cause personnel casualties or property damages.

〔Installation Instruction〕



Warning



Never install by yourself.

Split type air conditioner will work for you for a long period of time if it is correctly installed. Improper installation could cause problems such as leakage of water or refrigerant, electric shock or fire.



Caution

Please confirm the following before installation



Power specifications

Make sure that the capacity of socket or breaker and power cable is sufficient, the voltage is correct and the socket or breaker is grounded. There may be hazard of fire or electric shock otherwise.



Proper connection of wires and piping

Improper connection may decrease the efficiency or cause air conditioner stop running. Water or refrigerant leakage may be resulted as well.



Installation environments

Do not install air conditioner at the place where there is flammable or corrosive air.



Operating instruction

Please operate air conditioner in accordance to this manual.

【Operating Instruction】

WARNINGS

Following the safety messages is very important. These messages can save you from being injured or killed. Warning symbols alert you to be careful and means danger. Always follow instructions to be safe and reduce chances of injury or death. Warning and danger signs will precede safety messages.

Electrical safety

Grounding: This room air conditioner must be grounded.



Grounding reduces the risk of electric shock by providing an escape wire for the electric current.

If the power cord has a grounding plug with a grounding wire, plug it into an outlet that is properly installed and grounded.

If the power cord has not a grounding plug with a grounding wire, the grounding wire must connect the breaker that is properly installed and grounded.

Warning: Improper use of the grounding plug or breaker can result in a risk of electric shock. Call a qualified electrician if you don't understand the grounding instructions or if you are not sure if the air conditioner is properly grounded. If the wall outlet or breaker is not grounded, please contact an electrician to have it replaced with a properly grounded outlet or breaker.

Do not, under any circumstances, cut or remove the third (ground) prong from the power cord.

Adapter plug: We strongly advise against using an adapter plug or breaker.

Operating conditions

1. Temperature: T1 instance: -7°C~43°C (16°C~43°C in cooling-only type)

T3 instance: -7°C~52°C (16°C~52°C in cooling-only type)

If the unit runs beyond the temperature for a long time, it may cause cooling capacity to decrease or protector to work.

2. Relative humidity: <80%

If the unit runs beyond the humidity range, condensate may be formed near blade and outlet of air conditioner. It's normal.

3. In heating operation, strange smell may come from the unit. It is Normal phenomenon.

4. The performance parameters refer to name plate.

5. The waterproof level of indoor unit is IPX0. Do not use it in the laundry or bathroom.

6. The outdoor unit can't be installed in a closed area.
7. Fuse:50T T3.15AL250V or F3.15AL250V, rated current:3.15A.

Tips


- Install the unit on the north side, as normally that is the shaded side. This will enhance the operation of your unit.
- Use correct electric voltage and proper ampere for the unit to run effectively.
- Only let a certified electrician do any modifications to your electrical outlet or breaker.
- Use a dedicated line for the operation of your air conditioner to avoid the possibility of an electrical surge.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- The dimensions of the space necessary for correct installation of the appliance including the minimum permissible distances to adjacent structures.
- The appliance shall be installed in accordance with national wiring regulations.
- Disconnect the power supply before cleaning and maintenance.
- If the appliance is not connected by plug , an all-pole disconnection device which has at least 3mm separation distance in all pole and a residual current device(RCD)with the rating of above 10mA shall be incorporated in the fixed wiring according to the national rule.
- If the appliance is connected by plug , it must be positioned so that the plug is accessible.

Energy Saving Guide


- When installing your air conditioner make sure to seal all areas where there is a possibility of air leakage.
- Airflow should not be blocked inside either by curtains, drapes or furniture or outside by shrubs or bushes.
- Do not needlessly use an electrical light or other appliances that produce heat.
- Keep the blinds and the drapes drawn on all the other window.
- While cooking use an exhaust fan in the kitchen to remove the excess heat produced.

【Operating Instruction】


Only single-phase a.c. power can be used.
please refer to nameplate for details.



Use the specified power cord; do not change it.



Do not put fingers or sticks into the inlet or outlet of air conditioner; the running fan may cause injuries.



Do not put anything on the outdoor unit.



Do not switch on or off the unit by plugging or pulling off the plug, or by switching on or off the breaker.




Keep indoor ventilated, especially when there is operating gas equipment.



Do not substitute fuse with lead wire or other materials.



Pull off power plug or switch off breaker if the air conditioner is not used for a long time.



【Safety Instruction】



Warning:

The appliance is not intend for use by young children or infirm persons without supervision.
Young children should be supervised to ensure that they do not play with the appliance.

If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.

Don not connect the earth line to gas pipe, water pipe. Improper grounding may cause electric shock.




Do not pull off the power plug or switch off the breaker when it is in operation.



Switch off the unit; cut off the power source and contact service agent if there is abnormal phenomenon (e.g. burning smell comes out).



Do not install air conditioner at the place where flammable gas may leak.




Do not place plants or animals directly in the path of the air conditioner's airflow. Doing so could harm them.




Please contact service agents for service. Improper service may cause accident.



Switch off the unit, cut off the power source and make sure the fan stops before cleaning the unit.



For removal and installation of air conditioner, please refer to professionals or contact service agents.



PRODUCT INTRODUCTION

【Protect Functions】

Protect functions can prolong the air conditioner's service life and provide more comfortable airflow.

Delay-starting protection for the compressor

The compressor will restart working at least 3 minutes (5 minutes in heating mode) after being turned off to keep the pressure balance of the cooling system.

Remarks: There will be 1 minute for the compressor to work after the unit is electrified for the first time.

Defrosting (not available for cooling-only type air conditioner)

The outdoor heat exchanger may frost if the outdoor temperature is low and humidity is high. In this case, auto-defrosting has operated for 3~10 minutes. pause indicator(red) will be on, indoor and outdoor fan stop.

Heating overload protection (not available for cooling-only type air conditioner)

When the temperature of indoor pipe is too high, air conditioner enters heating overload protection. And indoor fan speed should be adjusted to a higher gear automatically. Outdoor fan and compressor may be stopped. When indoor pipe temperature drops to a rated value, air conditioner will exit heating overload protection. Indoor fan motor resumes to the normal status.

Blowing residual heat function (not available for cooling-only type air conditioner)

Indoor fan will keep running at low fan speed for 80 seconds when air conditioner is stopped in heating mode.

Cooling airflow proof (not available for cooling-only type air conditioner)

In the first several minutes of heating operation, PAUSE indicator lights; indoor fan doesn't run and louver blades can not be controlled. About 5 minutes later, air conditioner will blow heat airflow, PAUSE indicator is off.

Freeze-prevention

To prevent indoor heat exchanger freezing in cooling and dehumidification operation, compressor or outdoor fan may stop running; indoor fan speed will be adjusted to a higher gear automatically.

Dry for enzyme-prevention

Indoor fan motor will go on running for 3 minutes at low fan speed when turned off in cooling mode in order to keep dry condition inside the unit.

Reset power or Auto restart(alternative)

Reset power: When there is a power suspension, air conditioner will automatically switch off. When the power is back, the unit will automatically reset power. For energy saving if there is no person in the room, air conditioner will stay in PAUSE status. User needs to turn on Air conditioner by remote controller.

Auto restart: The unit memories the operation mode, air flow setting, temperature setting etc., so that should there be a power failure when the unit is in operation, it will automatically return the same operating conditions when the power is restored.

Cooling overload working (optional)


In cooling operation, if the temperature of outdoor heat exchanger is too high, indoor fan speed will be adjusted to a lower gear automatically and compressor may be stopped.

Drip proof (optional)

In cooling and dehumidification operation, louver blades can change the position automatically to prevent from dripping.

DESCRIPTION OF COMPONENTS

[[View of Unit]]



Remarks:

The air conditioner is consisting of indoor unit, outdoor unit and remote controller. The design and shape are different for different models. The above figures are only schematic, and they may be slightly different from the actual appliances you selected.

[[Display screen]]



Receiver : This receiver receives signal from remote controller.



“PAUSE” indicator : This indicator lights red when air conditioner is in defrosting or Cooling airflow proof mode.



“RUN” indicator : This signal light is on when the unit is in “RUNNING” status.



“TIMER” indicator : This signal light is on when the unit is in Timer.



“AIR REFRESH” indicator : This signal light is on when the unit is running in air refresh mode (optional).



“Temperature” indicator : This display can show the set temperature.

Remarks:

1. Flashing of any indicator means the air conditioner runs abnormally, please contact the distributor in time.
2. Function a: The air conditioner will only display “RUN” indicator to save electricity if it do not receive any signal from remote controller in 30 second s. If it receives signal from remote controller for the second time, the display will still show the corresponding indicators.

Function b: The indicators on the display screen can be still controlled by “ sleep” button on remote controller.

NOTE: Function a or function b is optional, and it is designed already before the product is dispatched from factory.

- 3.If there is any difference with the description mentioned above by your air conditioner, please refer to next pages.

[[Indicator light]]

① "PAUSE" indicator

This indicator lights red when air conditioner is in defrosting or Cooling airflow proof mode.

② "RUNNING" indicator

This indicator lights green when the unit is in "RUNNING" status; air conditioner is in HEAT, COOL, SWEEP, DRY mode.

③ "TIMER" indicator (Yellow)

This indicator lights yellow when the unit is in TIMER mode.

④ "AIR REFRESH" indicator (Green) (optional)


This indicator lights green when the unit is in Air Refresh operation, and it will not light if the unit does not have Air Refresh function.

⑤ "RECEIVER" indicator

This receiver receives signal from remote controller.

Note: If one of the "RUNNING", "PAUSE" or "TIMER" indicator flashes, please contact the distributor in time.


【Remote Controller】



Remarks :

1. Temperature can be set between 16°C~32°C.
2. The function and display of Heat is not available for cooling-only air conditioner.
3. When there is something wrong with the remote controller, please remove the batteries out, and then, encase the batteries in the remote controller again after a little.
4. The above illustration of remote controller is only for reference, it may be slightly different from the actual product you selected.

【Remote Controller Display】



Instruction for remote controller


- The remote controller uses two AAA alkaline batteries. Under normal condition, the batteries last for about 6 months. Please use two new batteries of similar type (pay attention to the poles when installing).
- The effective control distance of the remote controller is about 6m.
- When using remote controller, please point the signal emitter towards indoor unit receiver; There should be no obstacle between remote controller and indoor unit.
- Pressing two buttons simultaneously will result in wrong operation.
- Do not use wireless equipment (such as a mobile phone) near indoor unit. If interference occurs because of this, please switch off the unit, pull out power plug, then plug again and switch on after a while.
- There should be no direct sunlight to the indoor receiver, or it can not receive the signal from the remote controller.
- Don't cast the remote controller.
- Don't put the remote controller under the sunlight or near the oven.
- Don't sprinkle water or juice on the remote controller, use soft cloth for cleaning if it occurs.

- The batteries must be removed from the appliance before it is scrapped and that they are disposed of safety.

NOTE:The unaccounted symbol on the remote controller display is not available.

OPERATING METHOD

【SMART OPERATION】



Remarks:

1. When pressing “SMART” Button, the air conditioner will choose “COOL” , “HEAT” or “SWEEP” mode and choose operation parameter automatically according to the room temperature.
2. In the “SMART” mode, you can regulate the fan speed, fan sweep and set temperature ,etc.
3. In the “SMART” mode, all the additional functions of the air conditioner will be available. However, if your air conditioner does not have the additional functions or the additional functions conflict with the present operation mode (AUH is not available when cooling) ,the additional functions are ineffective.


【Emergency Run】

When the remote controller is missing or the batteries are run out, you can use the Emergency Button.

Operation Method:

Under the “OFF” condition, open the front board and press Emergency Button with the tip end of a ball-pen or the like and the air conditioner will operate in “SMART” mode. Press Emergency Button again to switch off the unit.

【COOL, DRY, SWEEP and HEAT OPERATION】



Remarks:

- When “DRY” mode is set, in accordance with the D-value between indoor temperature and set temperature, the air conditioner will start or stop the cooling operation and fan speed automatically to decrease room humidity. Fan speed can't be controlled sometimes.
- When “SWEEP” mode is set, the setting temperature on remote controller can not be adjusted. The air conditioner will run according to 24°C.

3. The remote controller has not auto fan speed in "SWEEP" mode.

【Off Timer】

Press "Off Timer", you can choose 1-8 hours circularly to turn off the air conditioner at the set time.



Remarks:

1. When off timer is set, air conditioner will be turned off at the set time.
2. Press "TIMER" to cancel "Off Timer" function and the air conditioner will stop if pressing "ON/OFF" Button.

【How to Adjust Air Flow】

Horizontal direction

Adjust the horizontal airflow direction by hand. (Fig. 1)



Louver blades

Vertical direction

Press the "SWING" on the remote controller repeatedly, louver blades can be set at the fixed position 1-5 (Fig. 2) or auto swing activates. In different modes, louver blades swings repeatedly in the set range.

Warning:

Fan inside;
Keep hands away!






Fig.2

【Sleep Operation】

1. When air conditioner is in on status, press "SLEEP" button to enter "SLEEP" mode, and will  display on the remote controller.
2. Press "SLEEP" button again,  will disappear on the remote controller, and the sleep (energy saving) function will be cancelled.

Note:

- 1.Function a: In sleep mode, the set temperature will be increased after running 1 hour in cool and DRY

mode; it will be decreased after running 1 hour in heating mode. The set temperature will be controlled between 16°C and 32°C. When air conditioner is in sleep mode, the highest indoor fan speed is set at medium level, but user can change the fan speed by remote controller.

2. Function b: In sleep mode, the set temperature and the indoor fan speed will not change, but the display screen of air conditioner will shut off except for the "RUN" indicator.

3. Function a or function b is optional, and it is designed already before the product is dispatched from manufactory.

SERVICE AND MAINTENANCE

Careful maintenance and overhaul in advance can prolong the air conditioner's service life and save electricity charges.

Caution:

1. Stop air conditioner by remote controller and cut off the power source before service and maintenance.
2. Do not stand on unstable objects when you clean or service air conditioner, or it may cause personnel injury.
3. Do not touch the metal part of the body when you remove the front panel, or it may cause personnel injury.



【Clean the Front Panel and Remote Controller】

If the dirt can't be removed, please clean it with warm damp cloth (soaked with warm water below 40°C)

Caution:

1. Do not clean the unit with water, or it may cause electric shock.
2. Do not clean the remote controller with water.
3. Do not clean with alcohol, gasoline, banana oil, or polishing.
4. Do not clean the unit violently, or it may cause the front panel falling down.
5. Do not clean the front panel or remote controller with metal brush; it may damage the surface.



【Clean Air Filter】




Fig. 4


1. Open the front panel. (Fig.4)
2. Lift the protruding part, then pull it downward, remove the air filter.
3. Clean it with vacuum cleaner or water. If air filter is very dirt, please clean it with warm soapy water or mild detergent. Then dry it in the shadow.
4. Insert air filter into the previous position, and close the front panel.

Note:


1. Air filter should be cleaned at least once every two weeks, or heating or cooling capacity will be reduced.
2. Do not clean the air filter with metal brush; it may be damaged.

【No Use for Long Time】


1. Swing 3-4 hours to dry the internal air conditioner.
2. Stop operation by remote controller, then cut off the power source of air conditioner.



3. Maintain air filter net.




4. Take out batteries from remote controller.



【Recommendations for Energy Saving 】


Appropriate Temp Setting

It is harmful to health if the room is too cold.



Avoid Direct Sunlight

When it is cooling, please use curtain or blind to obstruct direct sunlight.



Avoid Heat Sources

When it is cooling, using other heat sources may affect cooling effect.



Close Doors and Windows

Incoming outdoor air will affect the cooling or heating efficiency.



Keep Air Filter Clean

Keeping air filter clean ensures high efficiency operation.



Good Ventilation

Do not put objects in front of the inlet and outlet of outdoor unit.



TROUBLE SHOOTING

【Air Conditioner is in Error】

Checking before service.

Phenomenon	Checking Items
Air Conditioner Does Not Operate At All	1. Check whether the power is disconnected.
	2. Check whether the breaker is switched on or the fuse is burnt.
	3. Check the remote controller batteries.
	4. Check whether radio equipment is used within 1m around the unit.
Poor Cooling or Heating Performance	1. Check whether the air inlet or outlet is blocked.
	2. Check whether dust is blocking the filter.
	3. There may be too many people indoors.
	4. Check whether doors or windows are closed.
	5. Check whether fan speed or set temperature is improper.

【Remote Controller is in Error】

The following “trouble shooting” is normal phenomenon

Phenomenon	Checking Items
Fan stops or fan speed can not be controlled.	1. When air conditioner is in DRY mode or SLEEP mode, fan speed can't be controlled sometimes.
	2. When air conditioner is in COOL AIRFLOW PROOF or DEFROSTING operation (in HEAT mode), fan motor will stop.
	3. When air conditioner is in COOL or DRY mode, if air conditioner enters freeze-prevention operation, then fan speed can not be controlled.

4. When air conditioner is in HEAT mode, if air conditioner enters heating overload prevention operation, then fan speed can not be controlled.

[[failure code]]

code	Failure indication
F4	The circuit of indoor PG motor is damaged or abnormal
F1	The circuit of room temperature sensor is damaged or abnormal
F2	The circuit of indoor coil pipe temperature sensor is damaged or abnormal

NORMAL PHENOMENONS

When it is heating or cooling, plastic substance may give out a sound because of the temperature change.



If the indoor humidity is too high, water drops may form on the front grill of indoor unit. This is a normal phenomenon.




There may be gentle "rustle" sound when the unit starts or stops. It is the normal sound of flowing refrigerant.



Walls, carpet, furniture or clothes indoors may disseminate peculiar smell.



In order to protect the unit, when the compressor stops, there will be a 3-minute delay before restarting.



In the first several minutes of heating operation, wind may not come out from the indoor unit.



Water may flow out from the outdoor unit during heating operation.

In heating operation, steam may come out when it is defrosting.

INSTALLATION MANUAL

【Installation Guide】

- This air conditioner meets the safety and operation standards promulgated by the Nation.
- You need to invite professional air conditioner service and maintenance personnel to install or remove the air conditioner. Problems may occur and you may suffer losses if non- professionals install the air conditioner.
- User shall provide the power that meets installation and operation requirements. please refer to nameplate for details about the voltage for this product. Voltage beyond this scope will affect the normal operation of the air conditioner.
- Separate power point with delay fuse protector or automatic breaker should be used for the air conditioner.
- The air conditioner must be correctly and reliably grounded, or it may cause electric shock or fire.
- Do not switch on the power of the air conditioner before well connecting and carefully checking the tubing and wires.
- The appliance shall not be installed in laundry or bathroom.
- In case necessary, please consult your supply authority for system information.
- The plug shall be accessible after installed the appliance.
- This instruction is subject to change without notice.

【Installation of Accessories】

- Examine carefully the attached packing list and check whether the accessories are complete.
- Users may need to buy at their own expenses the articles not included in the packing list and may be needed in installing.

【Position for Indoor Unit】

- Away from the place where there is heat source, steam source, leakage of flammable gas and smoke.
- No obstacles near the inlet and outlet, and keep good ventilation.
- Good discharge for water.
- At least 1m away from wireless equipment (such as TV, radio etc.).
- Mounted on the wall that can bear the weight of the air conditioner and won't produce noise while unit working.




Fig.1

- The distance between the indoor unit and the floor should be greater than 2.3m.
- The plug shall be accessible after installing the appliance.
- Ensure the distance as required in Fig.1.
- The back of the indoor unit should be close to the wall(Fig.1)
- The all figures are only schematic, and they may be slightly different from the actual appliances you

selected.

【Position for Outdoor Unit】

- Avoid direct sunlight.
- Away from heat source, steam source, leakage of flammable gas, smoke and dust.
- Select a place that is away from rain (snow) and has good ventilation.
- Neighbors will not be affected by the blown wind and noise, or discharged water.
- The place that is easy to install and service.
- Mounted on the solid and reliable foundation will not increase noise or shock.
- To get high cooling performance, make sure the unit's front, rear, left and right sides must be located in an open area.
- The outlet is proposed to be in open air, any obstacle will affect the performances.
- The installing distance must be required as Fig. 2 shows.




Fig.2

【Tubing Selection】

- Ensure that the level (height) difference of indoor and outdoor units and the length of tubing meet the requirement in the Table 1.
- If the tubing is longer than 7m, but shorter than 15m, refrigerant should be supplemented according to Table 1.




Fig.3

Table 1

Tubing Size		Standard tubing Length (m)	Max tubing Length (m)	Height Difference (m)	Additional refrigerants(g/.m)
Narrow (mm)	Wide (mm)				
φ6.35(6.0)	φ9.52(9.0)	3.5	9	5	15
φ6.35(6.0)	φ12.7(12.0)	3.5	12	7	15
φ6.35(6.0)	φ15.88(5/8")	4	15	8	15

【Fixing Installation Panel】

- Dismantle the metal installation board of the indoor unit. Adjust the mounting panel to horizontal position.
- Drill holes and insert plastic expansion tubes at the appropriate locations on the wall and fix the installation board on the wall with M5x30 screws and washer 6. Ensure that there must be at least 4 fixed points in the wall. Ensure installation board to horizontal position.
- Drill holes as Fig. 4 shows. The hole, 80mm in diameter, should slightly slide down outwards..
- Cut PVC tubes at a slight angle in the length shorter than wall thickness and inset it into the hole.(Fig.5)
- Mount the wall cap.




Fig.4




Fig.5

NOTE : 1. Left chart is available for the position of drain hose. Refer to Fig.7.

2. Right chart is available for the position of drain hose. Refer to Fig.9.

【Indoor Unit Installation】

The tube may be connected in several directions as below shown Figures.

1. Connecting right back tube (similar to right lower tube) (optional, Refer to Fig.7)

- Pull out the tubing from bottom of the chassis; and connect the drainpipe. Strap the joint of tubing reliably.
- Lead the connecting wire to the indoor unit (Do not connect to the power).
- Strap together the tubes, discharge pipe and connecting wire with adhesive tape. The discharge pipe is put at the below.
- Remove the board which is on the chassis.
- Check if the connections are reliable.
- Mount the indoor unit on the two hooks at the upper part of installation board.




Fig.6

2. Connecting left back tube (similar to left lower tube). (optional, Refer to Fig9)

- Move the discharge tube to the left side, and discharge cap to the right side.
- Fix the tubes in the slot of the indoor unit with the fix clamp.
- The following mounting steps are the same as those in “1. Connecting right back tube.”




Fig.7





Fig.8

Fixed clamp Fig.9

【Outdoor Unit Installation】

- If installation brackets for installing outdoor unit are needed, user could buy the brackets from our company or agents (Fig.10) .
- Assemble the mounting frame and supports with the attached 6 screws (M12x25), plain washers, spring washers, and nuts.
- Drill 4 or more holes on the wall according to the feet size of the air conditioner. Determine the locations for mounting left and right supports. Ensure that the left and right supports are on the same level.
- Fix installation frame on the wall with expansive bolts.
- Fix outdoor unit with 4 bolts (M10x25) on the installation brackets.
- Fittings must be tightly screwed; Connection must be tight and reliable.
- In installing outdoor unit, the body should be hung with ropes to prevent from falling.
- In installing or repair, tools and components should be prevented from falling.
- Regularly check the reliability of the installation frame.




Fig.10

【Tubing Connection】

- Detach the valve cover of outdoor unit.
- Align flaring nut to the thread center, and screw the nut tightly by hand.
- Screw tightly the flaring nut with torque spanner until the torque spanner produces "click" sound.
- It is recommended to use torque spanner to connect the tubing. If other flexible or fixed spanner is used, it may damage the horn mouth due to improper force.
- The bending angle of the tube should not be too small or the tube may break up, so the service personnel should use tube bender to bend the tube.
- Never let water, dust or sand gets into the pipe.




Table 2

Tubing size (mm)	Torque (N. m)
φ6.35 (6.0)	15~20
φ9.52(9.0)	35~40
φ12.7(12.0)	50~55

【Connection of Wires】

1. Indoor unit

- Open upward the inlet grid to the greatest extends.
- Remove the electric cover from the unit.
- Loose the screw at connection lid. (Fig.12)
- Dismantle the wire pressure plate.
- Connect the power connecting wires and signal control wire separately to the corresponding terminals. (In Fig.14, please choose the same wiring diagram just with the wiring diagram of unit .)
- Loose off the screw on the earth plate; press earth wire tightly.
- Press tightly the connecting wires of the unit with lead wire pressure plate.
- Close the connection lid screw it tightly and close the inlet grid.




Fig.12

2. Outdoor unit

- Unscrew and dismantle the electronic device lid(Fig.13).
- Dismantle the pressure plate of wire fastener.
- Connect the connecting wires of the unit separately to the corresponding terminals. (Fig.14)
- Press tightly the connecting wires of the unit with top pressure plate.
- Remount the electronic device lid to the original position.

If user wants to prolong or replace the power wire, please do it according to the table(Table3).







Table 3

		Power connecting wires	Signal control wire	Power cord
	Max. Length	10m	10m	5m
7K/9K/12K/16K	Cross sectional area	$\geq 2.5 \text{ mm}^2$	$\geq 1.5 \text{ mm}^2$	$\geq 1.5 \text{ mm}^2$
18K/21K/24K		$\geq 2.5 \text{ mm}^2$	$\geq 1.5 \text{ mm}^2$	$\geq 2.5 \text{ mm}^2$



7K/ 9K/ 12K/ 16K



18K



9K/12K/18K/24K DC Inverter



21K/24K/28K






Fig.14

Notes:

- Earthing screw must use special screw(stainless machining screws or copper screws M4)
- Ensure that all wires are securely connected, will not loose or separate.
- Ensure that wire connections are carried out according to the wiring diagram of the air conditioner.
- The above figures are only schematic, and they may be slightly different from the actual appliances you select

【Tube Strapping】

- Strapping with PVC Protective tape must be careful, do not damage the pipeline and drain pipe.
- Strapping should start from the lower part of the outdoor unit to the indoor unit.
- Fix the PVC tape with adhesive tape to prevent losing.
- Drainpipe should slightly slide down outwards to ensure drainage well.
- When the indoor unit is lower than the outdoor unit, bend the tube to proper extent to prevent water draining into house.
- Fix the tube bundle with tube clamps on the wall.
- Allow enough space between discharge pipe and the ground. Do not put the discharge pipe in water or ditch.
- Seal the external wall holes with sealing gum or putty.




Fig.15

[[Exhaust]]

1. Exhausting type

- Make sure that all the tubes of indoor and outdoor unit are connecting well.
- Take off valve bonnet and service port valve bonnet from two-port valve (small pipe cut-off valve) and three-port valve (large pipe cut-off valve).
- Turn counter-clockwise 1/4 turn the spool of two-port valve, close after 10 seconds.
- To check whether there are leakage at all connections.
- If there is no leakage, turn again two-port valve counter-clockwise 1/4 turn, at the same time hold out against the exhaust from valve inside of service port of three-port valve for 10 seconds.
- Open two-port and three-port valves for running.
- Screw tightly the valve bonnet.
- Check with soap water or leak detector whether there are leakage at all indoor and outdoors' connections.
- Put the valve bonnet and valve cover back to the position.




Fig.16

2. Pumping type

- Make sure that all the tubes of indoor and outdoor unit are connecting well.
- Take off valve bonnet from two-way and three-way valves by spanner; connect vacuum pump and compound valve to the service valve bonnet.
- Open the low-pressure switch of compound valve, and run vacuum pump until units' internal pressure at 10 mmHg.
- After pump vacuum, close the low-pressure switch of compound valve, and then close vacuum pump. Turn anti-clockwise 90° Spool of narrow pipe service valve by hexagon spanner, tightly with clockwise turning after stopping for 10 seconds.
- Check with soap water or leak detector whether there is leakage at all connections of indoor and outdoor unit.
- Open wide and narrow pipe service valves by hexagon spanner for running.

- Take off the connection pipeline of wide pipe service valve.
- Screw tightly the entire valve bonnet by torque spanner.
- Check with soap water or leak detector whether there are leakage at all indoor and outdoors' connections.
- Put the valve bonnet and lid back to position.




Fig.17


【Drainage】

1. No need drainage treatment

In regions where become cold in the winter, don't install the drain elbow joint to prevent drain water from freezing and causing the fan to be damaged. This drainage treatment is not necessary for cooling-only type air conditioner.

2. When need drainage treatment

- Please use drain elbow joint (in accessory bag). Outdoor unit should be placed on blocks.



[[Installation for the cover of valve]] (optional)

For the whole unit that individual cover of valve is available (refer to packing list), the installing method is as follow:

After connecting the connection pipes between indoor and outdoor units followed by the installing method mentioned above, take out the cover of valve from the accessory bag, and fix it on the side of outdoor unit with three corresponding screws (inside the accessory bag).

